


# Powerwash Chrome OS

1. Plug Chromebook into power.
2. Put Chromebook into Recovery Mode by hitting Esc+Refresh() +Power
3. Hit Ctrl+D
4. Hit Enter
5. Hit Spacebar
6. Hit Enter
7. At the Welcome screen, select Let's Go
8. At the Connect to network screen, Select Wireless Network.
9. Hit Continue
10. Hit DONE when prompted.

